



### 00-7 Press

**Key**

No.	Part No.	Description
01	050004	Large Primer Tube
02	050005	Small Primer Tube
03	050018	APF Body Complete
05	190213	Primer Arm
06	190214	Frame
07	190215	Toggle
08	380053	Shell Holder Retainer Spg
09	390005	Small Primer Cup
10	390006	Large Primer Cup
11	390007	Primer Cup Spring
12	390027	Jam Nut
13	390034	Small Primer Punch
14	390035	Large Primer Punch
15	390062	APF Flat Washer
16	390063	APF Spring Screw

**Key**

No.	Part No.	Description
17	390070	Link Pins (2)
18	390071	Links (2)
19	390072	Ram Toggle Pin
20	390081	Toggle Pin E Clips (4)
21	390640	Hitch Pin
22	390657	Operating Lever
23	390661	Roll Pin
24	390666	APF Body Spring
25	390697	Ram
26	392010	APF Adjusting Screw
27	480087	APF Body
28	480088	Handle Knob
29	480090	Primer Catcher
	390036	Short-Arm Hex Allen Wrench (Not Shown)
	050019	Primer Arm Complete